



'72 TELECASTER THINLINE 0137402




'72 TELECASTER THINLINE 0137402

PICKGUARD ASSEMBLY



BRIDGE ASSEMBLY




'72 TELECASTER THINLINE 0137402

REF.#	P/N	DESCRIPTION
1	0054570000	Neck, '72 Telecaster Thinline, M/N
2	0053684000	Tuning Key, (1) Set
	0011357000	Mounting Screw
3	0083675000	Bone Nut
4	0010389000	String Retainer
	0011357000	Mounting Screw
5	0010286000	Truss Rod Adjustment Bullet
	0023811000	Truss Rod Adjusting Wrench
6	0054569xxx	Body, '72 Telecaster Thinline, Ash
7	0054525000	Neck Mounting Plate
	0015636000	Mounting Screw
	0020972000	Tilt Adjustment Screw
	0023811000	Tilt Adjusting Wrench
8	0012156000	Adjustment Bolt
9	0012344000	Strap Button
	0015610000	Mounting Screw
10	0054571002	Pickguard, '72 Telecaster Thinline, Shell
	0015578000	Mounting Screw
11	0054595000	Pickup, Neck, Humbucker, Fender Wide Range
	0050166000	Mounting Screw
	0050167000	Spring, Humbucker
12	0054200000	Pickup, Bridge, Humbucker, Fender Wide Range
	0050166000	Mounting Screw
	0050167000	Spring, Humbucker
13	0019064000	Control, 250k (2)
	0016352000	Mounting Hex Nut
	0016436000	Lock Washer, Intl
14	0013359000	Knob, Knurled, Chrome (2)
	0028897001	Set Screw
15	0053290000	Switch, Lever 3 - Position
	0021413000	Mounting Screw
	0018359000	Knob, Black
16	0024832000	Capacitor, .022uf
17	0047329000	Output Jack
	0016352000	Mounting Hex Nut
	0016436000	Lock Washer, Intl
18	0021452000	Jack Ferrule
19	0021429000	String Retainer, Ferrule
20	0037592000	Bridge Assembly, Vintage Stratocaster
	0015610000	Mounting Srew
21	0010322000	Bridge Plate, Vintage Stratocaster
22	0019280000	Bridge Section, (6)
23	0015693000	Intonation Screw, (6)
	0019273000	Intonation Spring, 5&6
	0019281000	Intonation Spring, 1-4
24	0032782000	Height Adjustment Screw, Black 1-6
	0016071000	Height Adjustment Screw, Black 2-5
	0018531000	Adjusting Wrench, Saddle Height

Body Part Number	
0054569500	3 Color Sunburst
0054569521	Natural

'72 TELECASTER THINLINE 0137402

SWITCH & FUNCTION CONTROL



DETAIL 3 WAY SWITCH DIAGRAM

3 WAY SWITCH POSITION			
● 3 ○ ○	○ 2 ● ○	○ ○ 1 ●	← 3 WAY SWITCH POSITION
■	■	□	← NECK PICKUP
□	■	■	← BRIDGE PICKUP
□	PICKUP IS OFF	■	PICKUP IS ON

